




- ① (20 AMP.) TURN SIGNALS, BACK-UP LAMPS, WINDSHIELD WASHER, RADIO FEED AND PRNDL LAMP (AUTO. TRANS.)
- ② (20 AMP.) (ACCESSORY FEED) SEAT BELT WARNING (RPO), SWING TILT COLUMN (RPO) SAFETY CONVENIENCE CIRCUIT-DOOR AJAR, LOW FUEL, POWER WINDOW SAFETY RELAY FEED, SPEED CONTROL
- ③ (14 AMP.) HEATER AND DEFROSTER
(30 AMP.) AIR CONDITIONER
- ④ (SPARE)
- ⑤ (4 AMP.) INSTRUMENT AND CLUSTER LAMPS, RADIO, HEATER CONTROLS, CLOCK, ASH TRAY LAMP
- ⑥ (14 AMP.) COURTESY, INSTRUMENT, DOOR, DOME, MAP, GLOVE BOX, "C" PILLAR, LUGGAGE COMPARTMENT LAMP, CLOCK FEED, CIGAR LIGHTER
- ⑦ (20 AMP.) EMERGENCY WARNING

NOTE: (30 AMP. REQUIRED FOR AIR/COND.)